



Installation Instructions


RM 100




RM 100 remote control



RM 100 Receiver




Power Supply




5' Power Extension Cord

Connect the light

1. Connect to Power Supply and LED Light.





2. Press the Learning Key shortly, and short press the power button. Once you do that, the LED lights will blink once. Now your remote and receiver are paired!




3. button to turn ON/OFF LED lights.

button to adjust brightness.




Battery replacement

1. Take off the rear cover of remote control, remove the battery, replace a new one. **Please make sure that you insert the batteries correctly with the PLUS and MINUS (+ and -) on the right side.**



2. When place the new one, please note the battery should be clip in the groove. Close the battery cover.



Memory Reset

In case you want to reset the memory of the receiver, press the learning function button for 10 seconds while the unit is being powered.

The unit will then reset to factory defaults.

